

# Pressure Torque Table

**Tool Model**      W2000PX  
**Brand**            Enerpac  
**Company**        kNm Hydraulikk



**ENERPAC** 

Pump Pressure		Torque		
Psi	Bar	Nm	Ft.lbs	kgm
870	60	241	178	25
1305	90	361	266	37
1740	120	481	355	49
2176	150	601	443	61
2611	180	722	533	74
3046	210	842	621	86
3481	240	962	710	98
3916	270	1082	798	110
4351	300	1203	887	123
4786	330	1323	976	135
5221	360	1443	1064	147
5656	390	1563	1153	159
6092	420	1684	1242	172
6527	450	1804	1331	184
6962	480	1924	1419	196
7397	510	2044	1508	208
7832	540	2165	1597	221
8267	570	2285	1685	233
8702	600	2405	1774	245
9137	630	2525	1862	257
9572	660	2646	1952	270
10000	690	2766	2040	282

*\*Please note this table is only valid for Enerpac W2000PX and W2000P*

**kNm Hydraulikk**  
**Skvadronvegen 27**  
**4050 Sola**

[www.kNm-hydraulikk.no](http://www.kNm-hydraulikk.no)

**Tlf: 95 25 13 10**  
**post@kNm-hydraulikk.no**

# Pressure Torque Table

**Tool Model**      **W4000PX**  
**Brand**            **Enerpac**  
**Company**        **kNm Hydraulikk**



**ENERPAC** 

Pump Pressure		Torque		
Psi	Bar	Nm	Ft.lbs	kgm
870	60	492	363	50
1305	90	738	544	75
1740	120	984	726	100
2176	150	1231	908	126
2611	180	1477	1089	151
3046	210	1723	1271	176
3481	240	1969	1452	201
3916	270	2215	1634	226
4351	300	2461	1815	251
4786	330	2707	1997	276
5221	360	2953	2178	301
5656	390	3199	2359	326
6092	420	3446	2542	351
6527	450	3692	2723	376
6962	480	3938	2905	402
7397	510	4184	3086	427
7832	540	4430	3267	452
8267	570	4676	3449	477
8702	600	4922	3630	502
9137	630	5168	3812	527
9572	660	5414	3993	552
10000	690	5661	4175	577

*\*Please note this table is only valid for Enerpac W4000PX and W4000P*

**kNm Hydraulikk**  
**Skvadronvegen 27**  
**4050 Sola**

[www.kNm-hydraulikk.no](http://www.kNm-hydraulikk.no)

**Tlf: 95 25 13 10**  
**post@kNm-hydraulikk.no**

# Pressure Torque Table

**Tool Model**      W8000PX  
**Brand**            Enerpac  
**Company**        kNm Hydraulikk



ENERPAC 

Pump Pressure		Torque		
Psi	Bar	Nm	Ft.lbs	kgm
870	60	999	737	102
1305	90	1498	1105	153
1740	120	1997	1473	204
2176	150	2496	1841	255
2611	180	2996	2210	306
3046	210	3495	2578	356
3481	240	3994	2946	407
3916	270	4494	3315	458
4351	300	4993	3683	509
4786	330	5492	4051	560
5221	360	5992	4419	611
5656	390	6491	4788	662
6092	420	6990	5156	713
6527	450	7489	5524	764
6962	480	7989	5892	815
7397	510	8488	6260	866
7832	540	8987	6628	916
8267	570	9487	6997	967
8702	600	9986	7365	1018
9137	630	10485	7733	1069
9572	660	10984	8101	1120
10000	690	11484	8470	1171

*\*Please note this table is only valid for Enerpac W8000PX and W8000P*

**kNm Hydraulikk**  
**Skvadronvegen 27**  
**4050 Sola**

[www.kNm-hydraulikk.no](http://www.kNm-hydraulikk.no)

**Tlf: 95 25 13 10**  
**post@kNm-hydraulikk.no**

# Pressure Torque Table

**Tool Model**      W15000PX  
**Brand**            Enerpac  
**Company**        kNm Hydraulikk



ENERPAC 

Pump Pressure		Torque		
Psi	Bar	Nm	Ft.lbs	kgm
870	60	1807	1333	184
1305	90	2711	2000	276
1740	120	3615	2666	369
2176	150	4518	3332	461
2611	180	5422	3999	553
3046	210	6326	4666	645
3481	240	7229	5332	737
3916	270	8133	5999	829
4351	300	9037	6665	922
4786	330	9941	7332	1014
5221	360	10844	7998	1106
5656	390	11748	8665	1198
6092	420	12652	9332	1290
6527	450	13555	9998	1382
6962	480	14459	10664	1474
7397	510	15363	11331	1567
7832	540	16266	11997	1659
8267	570	17170	12664	1751
8702	600	18074	13331	1843
9137	630	18977	13997	1935
9572	660	19881	14663	2027
10000	690	20785	15330	2119

*\*Please note this table is only valid for Enerpac W15000PX and W15000P*

**kNm Hydraulikk**  
**Skvadronvegen 27**  
**4050 Sola**

[www.kNm-hydraulikk.no](http://www.kNm-hydraulikk.no)

**Tlf: 95 25 13 10**  
**post@kNm-hydraulikk.no**